



TECNOLOGÍA NAVARRA DE NANOPRODUCTOS S.L. (TECNAN)  
Área industrial Perguita c/A, 1  
31210 Los Arcos (Navarra-SPAIN)  
Tel. 948 640 318  
Fax. 948 640 319  
[www.tecnan-nanomat.es](http://www.tecnan-nanomat.es)  
e-mail: [tecnan@tecnan-nanomat.es](mailto:tecnan@tecnan-nanomat.es)



## TECNADIS GWR – Directions to use on windscreen

### HOW TO USE IT

#### STEP 1:

WARNING! SURFACE MUST BE COMPLETELY CLEAN AND DRY BEFORE APPLYING. To do so it is recommended to use suitable cleaning products. Afterwards, all traces of detergents and cleaners should be completely removed.



#### STEP 2:

THE PRODUCT CAN BE APPLIED DIRECTLY ONTO THE SURFACE WITH A SPRAY helping yourself with a microfiber cloth or paper to distribute the product evenly throughout the area. IT CAN ALSO BE APPLIED DIRECTLY TO THE CLOTH.



#### STEP 3:

IMMEDIATELY AFTER APPLYING PRODUCT, POLISH THE EXCESS PRODUCT WITH A DRY CLOTH. The product has to be perfectly distributed and fully transparent.



### LIMITATIONS

Apply with the glass surface completely clean and dry. Avoid conditions of extreme humidity when applying.

It is advisable not to perform the treatment when the windscreen or glass is directly facing sun, or the surface is too hot.

When applied twice or more, the glass has hydrophobic properties which last longer. There is no need to remove previous applications.

It is not necessary to leave a time of drying/curing. The glass can be subjected to the action of the water/rain immediately after the application, although after a timeout of 1-2 hours, the water repellency effect reaches its optimum point.